



# NIGHTSPYER™

MICRO NIGHTSCOPE

Ages 5 and Up  
70056

Requires 2 386  
(LR43) button cell  
batteries, included.

**IMPORTANT: KEEP THESE INSTRUCTIONS. DO NOT DISCARD.**

## FEATURES

- Focused red light beam lets you see in the dark up to 25 feet (7.6 meters).
- Easy to operate ON/OFF switch.
- 2X power telescope aimed to view lighted area.
- Batteries included.

## TO OPERATE NIGHTSPYER



- Make sure you are in a dimly lit to dark area.
- Hold the NIGHTSPYER telescope to your eye.
- Press and hold the ON button.
- Release button to turn off.

## BATTERY INFORMATION

- Only adults should install and replace batteries.
- Two (2) 386 (LR43) batteries required for replacement.
- Alkaline batteries recommended for longer life.
- Do not use rechargeable batteries.
- Do not recharge non-rechargeable batteries.
- Remove exhausted batteries from the toy.
- Insert batteries matching the correct polarity.
- Do not short-circuit the battery supply terminals.
- Only use batteries of the same or equivalent type.
- Do not dispose batteries in a fire, they may explode.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.

## PARENTS: TO INSTALL BATTERY

- Using a Phillips screwdriver, completely loosen the battery door screw. This screw will not remove from the battery door.
- Remove the battery door and exhausted batteries.
- Insert new batteries per the marking on the battery door.
- Replace the battery door and tighten screw.



**CAUTION! DISCARD TOY IF LENSES ARE CRACKED OR BROKEN.**

**CAUTION! VIEWING THE SUN CAN CAUSE PERMANENT EYE DAMAGE. DO NOT VIEW THE SUN WITH THIS PRODUCT OR EVEN THE NAKED EYE.**

NIGHTSPYER 70056-4000-G2 11/07

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US AT  
1-800-247-6570

[WWW.WILDPLANET.COM/HELP](http://WWW.WILDPLANET.COM/HELP)

Wild Planet Entertainment, Inc., P.O. Box 420  
San Francisco, CA 94104-0420