



SPLIT-BLASTER™

Blaster with 2 Adjustable Barrels

Ages 6 and up
70316

Important: Please save this instruction sheet. It contains valuable product information.

DART USE AND STORAGE

- Shooting Darts: Insert one DART into each of the two LAUNCH PORTS until they lock into place. Press TRIGGER on handle to fire (Fig. 1). Both darts will fire at the same time.
- Storing Darts: Store up to two darts below the barrels by securing them in the brackets (Fig. 1).

ADJUSTABLE BARRELS

- To hit two targets at the same time, pivot each barrel in a different direction.
- Each barrel can pivot up to ninety degrees (Fig. 2).

Caution! Do not aim at eyes or face. To avoid injury: use only darts designed for this product. Do not modify darts or blaster.



SPLIT-BLASTER 70316-4000 PS 08/09

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US AT
1-800-247-6570
WILDPLANET.COM/HELP
Wild Planet Entertainment, Inc., P.O. Box 194087
San Francisco, CA 94119-4087

© 2009 Wild Planet Entertainment, Inc., San Francisco, CA 94104, USA.
All rights reserved. **PRINTED IN CHINA.** Product colors and specifications subject to change.
Conforms to ASTM D-4236

