



# Aqua Light Mask™

Swim Mask with Waterproof Headlights

Ages 6 and up  
9786

**Important: Please save this instruction sheet. It contains valuable product information.**

## PREPARING TO USE THE AQUA LIGHT MASK

1. To install the STRAP, see Fig. 1. (Note: Ribs should face out.)
2. To turn on the Aqua Light Mask, turn switch to "ON" (Fig. 2.)
3. When not in use, turn the switch to "OFF".

## FITTING THE AQUA LIGHT MASK

1. Place mask over your face and breathe in through your nose.  
If the mask is the right size, no air should leak through the mask.  
The mask will feel like a suction cup over your face.
2. Now adjust the STRAPS to fit comfortably and firmly around the face (Fig. 3.)
3. Test the mask in the water. If water leaks in, tighten the straps a little.

## ADULTS: REPLACING THE LIGHTBULB

1. Use two (2.5 V, 0.3 A, Type PR6) LIGHTBULBS. Replacements should be available in most electronics or hardware stores.
2. Locate the two lights on the front of the mask and unscrew the LENS CAP (Fig. 4.)
3. Remove the REFLECTORS.
4. Remove the old lightbulbs and discard.
5. Insert the new lightbulbs.
6. Replace the reflectors and lens caps. Make sure the lens caps are secured tightly to ensure that they are watertight.
7. Use two (2.5 V, 0.3 A, Type PR6) lightbulbs.

## ADULTS: REPLACING THE BATTERIES

1. Use four AAA (LR03) batteries (not included).
2. Use a small Phillips screwdriver to remove the BATTERY DOOR. (Fig. 5.)
3. Discard the old batteries and insert the new batteries per the polarity markings in the battery compartment, two per compartment (Fig. 6.)
4. Replace the battery door and the SCREWS. Make sure it is secured tightly to ensure it is watertight.

## THINK GREEN!

Consider using rechargeable batteries. Visit RBRC.org to find recycling centers in your area.

## BATTERY WARNINGS

1. Requires 4 AAA (LR03) batteries.
2. Only adults should install and replace batteries.
3. Rechargeable batteries are to be removed from the toy before being charged.
4. Rechargeable batteries are only to be charged under adult supervision.
5. Non-rechargeable batteries are not to be recharged.
6. Remove dead or exhausted batteries.
7. Insert batteries correctly. Match positive and negative signs.
8. The supply terminals are not to be short circuited.
9. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
10. Do not mix old and new batteries.
11. Only the batteries of the same or equivalent type recommended to be used.
12. Do not dispose batteries in a fire; they may explode.
13. Dispose of batteries safely.

**WARNING:** All underwater games are dangerous.

Use only under the supervision of an experienced swimmer.





Fig. 1




Fig. 2




Fig. 3




Fig. 4




Fig. 5




Fig. 6



AQUA LIGHT MASK 9786-4000-G1 05/09

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US AT  
1-800-247-6570  
WILDPLANET.COM/HELP  
Wild Planet Entertainment, Inc., P.O. Box 194087  
San Francisco, CA 94119-4087

© 2009 Wild Planet Entertainment, Inc., San Francisco, CA 94104, USA.  
All rights reserved. **PRINTED IN CHINA.** Foreign patents pending.  
Product colors and specifications subject to change.