



Pathfinder Tool™

6-in-1 Explorer's Tool!

Ages 4 and up
36008

Requires 3 G3-A (LR41)
button cell batteries,
included.

WARNING:
CHOKING HAZARD – Small Parts
Not for children under 3 years

Important: Please save this instruction sheet. It contains valuable product information.

TO USE THE SCOPE

The scope can be used 3 ways: as a telescope, as a magnifying glass, and as a scope for examining items held in the tweezers.

1. To use as a telescope, unfold both the **LARGE LENS** and **SMALL LENS**. Hold the Pathfinder Tool in front of your eye, line up the two lenses, and look through the small lens (Fig. 1).
2. To use as a **MAGNIFYING GLASS**, unfold the large lens only, and hold it above the item you want to see in more detail.
3. With the large lens unfolded, swing out the **TWEEZERS**. Look through the lens at the item held in the tweezers.

TO USE THE COMPASS

1. Hold the Pathfinder Tool level and still on the palm of your hand, with the **COMPASS** facing upwards.
2. Wait until the compass dial stops turning.
3. Read the direction.

TO USE THE LIGHT

1. Press the **POWER BUTTON** lightly and release to flash signals. Press power button all the way in to lock on for flashlight use. Press again to turn off.

BATTERY SAFETY INFORMATION

Note: Removable button cell batteries in this product contain mercury. When battery is replaced, don't put used one in trash. Recycle or dispose of according to local, state, or federal laws.

- Only adults should install and replace batteries.
- Do not recharge non-rechargeable batteries.
- Remove dead or exhausted batteries.
- Insert batteries correctly. Match positive and negative signs.
- The supply terminals are not to be short circuited.
- Do not use rechargeable batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only the batteries of the same or equivalent type recommended to be used.
- Do not dispose of batteries in a fire; they may explode.
- Dispose of batteries safely.

ATTENTION ADULTS — TO REPLACE BATTERIES

Pathfinder Tool requires 3 G3-A (LR41) batteries. (Size 384 can also be used.)

1. Locate the battery compartment (on the rear of the Pathfinder Tool). Use a small Phillips head screwdriver to loosen the screw, and remove the battery cover.
2. Remove all three batteries.
3. Place three new batteries in compartment as shown (Fig. 2).
4. Replace battery cover and tighten screw.

CAUTION: Viewing the sun can cause permanent eye damage. Do not view the sun with telescope, scope or magnifying glass or even the naked eye.



EX OPS™ PATHFINDER TOOL 36008-4000 PR 9/06
IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US AT
1-800-247-6570
WWW.WILDPLANET.COM/HELP
Wild Planet Entertainment, Inc., P.O. Box 194087
San Francisco, CA 94119-4087






Fig. 1

Fig. 2

© 2006 Wild Planet Entertainment, Inc., San Francisco, CA 94104, USA. All rights reserved. Product specifications subject to change. **PRINTED IN CHINA**