



Wrist Talkies™

Walkie Talkie Set!

Important: Please save this instruction sheet.
It contains valuable product information.

Battery Safety Information:

- Requires two 9V (6LR61) batteries (not included).
- Only adults should install and replace batteries.
- Do not recharge non-rechargeable batteries.
- Remove dead or exhausted batteries.
- Insert batteries correctly. Match positive and negative signs.
- Do not place anything across the battery terminals.
- Only use the batteries specified above.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Do not dispose batteries in a fire; they may explode.
- Dispose of batteries safely; recycle them where possible.
- Do not use rechargeable batteries.
- Only the batteries of the same or equivalent type recommended to be used.



Attention Adults -- To Replace Batteries:

Wrist Talkies requires two 9V (6LR61) batteries (not included).

1. Locate the battery compartment on the inner side of the Wrist Talkie. Use a small Phillips head screwdriver to loosen the two screws, and remove the battery cover.
2. Remove the exhausted battery.
3. Place the new battery in compartment as shown.
4. Replace the battery cover and tighten screw.
5. Repeat for the other Wrist Talkie.

How to use the Wrist Talkies:

1. Slip the Hand Strap over your fingers and attach the Wrist Strap around your wrist.
2. Flip up the Antenna.
3. Turn the On/Off/Volume Dial clockwise until you hear a click. Continue turning to adjust volume.
4. Press the Talk Button to speak (the Red Talk Light will switch on).
5. Release the Talk Button to listen.
6. To conserve battery life, when you have finished playing turn the On/Off/Volume Dial counter-clockwise until you hear a click.



Care

Avoid Dropping, bumping or smashing them. Don't immerse them in water and avoid getting them wet.



WRIST TALKIES

11311-4000

5/03

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US AT
1-800-247-6570
WWW.WILDPLANET.COM
©2002 Wild Planet Toys, Inc.



WARNING:

CHOKING HAZARD: Small Parts.
Not for Children Under 3 Years.