



# Spyder Trap™

Motion Alarm with 4 Trip Lines

Ages 6 and Up  
70273

**Important: Please save this instruction sheet. It contains valuable product information.**

### Operation

- Make sure batteries are installed correctly as indicated below.
- Pull the small **Spring Loaded Clips** and the large **Spring Loaded Clamps** away from Spyder Trap body. Each **Trip Line** extends about 30 inches in length. The Clips and Clamps have **Break-away Connectors** for safety that are easily snapped back into place.
- Attach all four Clips and Clamps to objects on either side of the area you want to keep secure. For best results the Trip Lines should form an "X" with the Spyder Trap body in the center. See Fig. 1.
- Once the Clips and Clamps are in place, tighten the Trip Lines for optimal security. Use the **Clamp Retract Buttons** and **Clip Retract Thumb Wheels** to adjust the tension on the Trip Lines.
- Turn on the **Power Switch** on the reverse side of the Spyder Trap body (Fig. 2) to activate the alarm. After several short beeps and a final arming sound, the trap is activated.
- Any movement of the Trip Lines or Spyder Trap body will set off the alarm siren. Use the Power Switch to deactivate and reset the alarm.
- When storing your Spyder Trap press the Clamp Retract Buttons, and use the Clip Retract Thumb Wheels to reel in the Trip Lines, Clamps and Clips.

### Attention Adults: To Replace The Batteries

- Requires three AAA (LR03) batteries, not included.
- Use a small Phillips screwdriver to loosen the screw on the battery compartment cover, Fig. 3.
- NOTE: Screws will not detach from battery compartment cover.
- Remove the cover.
- Place the batteries in the compartment as shown.
- Replace battery compartment cover and tighten screws.

### Battery Safety Information

- Only adults should install and replace batteries.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Non-rechargeable batteries are not to be recharged.
- Remove dead or exhausted batteries.
- Insert batteries correctly. Match positive and negative signs.
- The supply terminals are not to be short circuited.
- Do not mix different types of batteries.
- Do not mix old and new batteries.
- Only the batteries of the same or equivalent type are recommended to be used.
- Do not dispose batteries in a fire; they may explode.
- Dispose of batteries safely.

**NOTE:** As a safety precaution, avoid retracting cables when clamps are detached.

**Warning! Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

NOTE: This unit has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This unit generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this unit does cause harmful interference to radio or television reception, which can be determined by turning the unit off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the unit and receiver.
- Connect the unit into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.




Fig. 1




Fig. 2




Fig. 3



SPYDER TRAP 70273-4000 PS 10/08

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US AT  
1-800-247-6570  
WILDPLANET.COM/HELP  
Wild Planet Entertainment, Inc., P.O. Box 194087  
San Francisco, CA 94119-4087

© 2008 Wild Planet Entertainment, Inc., San Francisco, CA 94104, USA.  
All rights reserved. **PRINTED IN CHINA.**

Product specifications subject to change.