



Aqua Light Mask

Ages 5 & up!

IMPORTANT : Keep these instructions. DO NOT DISCARD.

- ¥ Requires 4 x 1.5V AAA (LR03) batteries.
- ¥ Requires 2 x (2.5V, 0.3 A, Type PR6) light bulbs, included.
- ¥ Only adults should install and replace batteries.
- ¥ Alkaline batteries are recommended for longer life.
- ¥ Do not use rechargeable batteries.
- ¥ Non-rechargeable batteries are not to be recharged.
- ¥ Exhausted batteries should be removed from the toy.
- ¥ Do not mix old and new batteries.
- ¥ Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel cadmium) batteries.
- ¥ Batteries should be inserted with the correct polarity.
- ¥ The supply terminals are not to be short-circuited.
- ¥ Only the batteries of the same or equivalent type as recommended are to be used.

Features: (Figure 1)

- ¥ Form fitting junior size mask
- ¥ Lights to see underwater in the dark
- ¥ Day or night use
- ¥ Adjustable strap

Battery Installation

The Aqua Light Mask requires 4 x 1.5 Volt AAA (LR03) batteries (not included).

To install the batteries:

1. With a small Phillips screwdriver, remove screws from the battery door. (Figure 2)
2. Remove the battery door.
3. Discard the old batteries.
4. Insert the new batteries per the polarity markings in the battery compartment, two per compartment. (Figure 3)
5. Replace the battery door and the screws. Make sure it is secured tightly to ensure it is watertight.




Figure 1




Figure 2




Figure 3

Aqua Light Mask Use (Figure 4 & 5)

1. To install strap, see Figure 4.
(NOTE: Ribs should face out)
2. To turn on the Aqua Light Mask, turn switch to "ON".
3. When not in use, turn the switch to "OFF".

Adjusting the Mask to Fit You

1. Place mask over your face and breathe in through your nose. If the mask is the right size, no air should leak through the mask. The mask will feel like a suction cup over your face.
2. Now adjust the straps to fit comfortably and firmly around the face. (Figure 6)
3. Test the mask in the water. If water leaks in, tighten the straps a little.





Note: If you tighten the straps too much, the water may also leak into the mask. It is important that the mask is adjusted just right before you go underwater.

Light Bulb Replacement

The Aqua Light Mask requires 2 x (2.5 V, 0.3 A, Type PR6) light bulbs.

To replace the light bulbs: (Figure 7)

1. Locate the two lights on the front of the mask and unscrew the lens caps.
2. Remove the reflectors.
3. Remove the old light bulbs and discard.
4. Insert the new light bulbs.
5. Replace the reflectors and lens caps. Make sure the lens caps are secured tightly to ensure that they are watertight.



WARNING:

All underwater games are dangerous. Use only under the supervision of an experienced Swimmer.

If you have any questions please contact us
1-800-247-6570
www.wildplanet.com

Aqua Light Mask
9786-4000PR1-12/13/99
WildPlanet Toys, Inc.

Figure 7