SKELEFLEX

DINO POWERFLEX LAB

6x

Add these FLEXIBLE joints at any connection point.



Using the T-Rex with the Powerlab Base:

- Slip the T-Rex feet into the Powerlab Base clips.
- Rotate the clips until they click, holding the T-Rex to the Powerlab Base as shown in Fig 1.
- Plug the Powerlab Cord into the Activation Port on the back of the T-Rex's pelvis as shown in Fig 2.
- Flip the Power Switch to bring your creature to life! Flip it forward and backward to change directions.



Important: Please save this instruction sheet. It contains valuable product information.

DINO POWERFLEX LAB
57005-4000 PS 05/08

IF YOU HAVE ANY QUESTIONS, PLEASE CONTACT US AT
1-800-247-6570
WILDPLANET.COM/HELP
Wild Planet Entertainment, Inc., P.O. Box 194087
San Francisco, CA 94119-4087

Ages 7+
57005

© 2007 Wild Planet Entertainment, Inc., San Francisco, CA 94104, USA. All rights reserved. **PRINTED IN CHINA.** Product specifications subject to change.

TM

Build and rebuild T-Rex any way you want!

Fang-o-flex / T-Rex monster mix

Attention Adults: To Replace The Batteries

- Requires 3 AA (LR06) batteries, not included.
- Use a small Phillips screwdriver to loosen the screw on the battery compartment cover on the bottom of the Power Base as shown in Fig. 3.
- NOTE: Screws will not detach from battery compartment cover.
- Remove the cover.
- Place the batteries in the compartment as shown.
- Replace battery compartment cover and tighten screws.



Fig. 3

Battery Safety Information

- Requires 3 AA (LR06) batteries, not included.
- Only adults should install and replace batteries.
- Do not recharge non-rechargeable batteries.
- Remove dead or exhausted batteries.
- Insert batteries correctly. Match positive and negative signs.
- The supply terminals are not to be short circuited.
- Do not use rechargeable batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
- Do not mix old and new batteries.
- Only the batteries of the same or equivalent type are recommended to be used.
- Do not dispose batteries in a fire; they may explode.
- Dispose of batteries safely.