





SPY TOOL KIT

AGES 8 AND UP!

ELECTRONIC GADGET SET

IMPOR TANT : Keep these instructions. DO NOT DISCARD

- Requires 1 x 9V (6LR61) battery for the Listening Device .
- Requires 2 x "AAA" (LR03) batteries for the Pen Light.
- Requires 1x2.2V,0.25 amp (type 222) bulb for the pen light.
- Only adults should install and replace batteries.
- Alkaline batteries are recommended for longer life.
- Do not use rechargeable batteries.
- Non-rechargeable batteries are not to be recharged.
- Exhausted batteries should be removed from the toy.
- Do not mix old and new batteries
- Do not mix alkaline, standard (carbon zinc) or rechargeable (nickel cadmium)batteries.
- Batteries should be inserted with the correct polarity.
- The supply terminals are not to be short-circuited.
- Only the batteries of the same or equivalent type as recommended are to be used.



To Assemble the Accessories to the Listening Device

Attach the Telescope/Microscope to either the top or the bottom of the S-clip.
Attach the Pen Light to the other location on the clip.

To Operate the Listening Device (Figure 2)

1. Pivot the microphone tube into the "up" position.
2. Plug the Earphones into the jack on the Listening Device.
3. Place the Earphones into your ears.
4. Point the Listening Device toward the sound you want to hear.
5. Press the on/off button with your finger to hear the sounds.

Important: To avoid feedback squeal,do not point the microphone directly at the earphones.

Telescope/Microscope Operation

To use the Telescope:

To focus the Telescope, slide the tubes in or out until the object becomes clear. (Figure 3)

To use the Microscope:(Figure 4)

1. Remove the upper tube from the lower tube. Use the upper tube.
2. Place the end of the Microscope (the end with the clear plastic) directly on the object which you intend to examine, vertical to the surface.
3. Look into the eyepiece.

Hint: If it is too dark to see the object,the Pen Light can be placed near the base of the Microscope. (Figure 4)

Pen Light Operation

The Pen Light is only a flashlight - it is not a pen.The term "Pen Light" is used to describe a flashlight the size of a pen.

Installing the Batteries

The Listening Device requires one 9V (6LR61) batter y. To install the battery:

1. With a small Phillips screwdriver, remove the screw from the battery door. (Figure 5)
2. Open the battery door.
3. Remove the old battery and discard.
4. Install the 9-volt battery to the connector jack. (Figure 6) When replacing the battery, carefully pry the battery apart from the connector jack.Then replace with a fresh alkaline (9-V) battery. Note the polarity requirements.
5. Replace the battery door and the screw to the original position.

The Pen Light requires two "AAA"(LRO3) batteries.

To install the batteries:

1. Unscrew the tube halves.(Figure 7)
2. Remove the old batteries and discard.
3. Insert the new batteries per the markings in the battery compartment.
Note polarity requirements.(Figure 8)
4. Reassemble the housing to the original position.

Installing the Light Bulb in the Pen Light

The Pen Light requires one 2.2 Volt,0.25 amp (type 222) bulb or equivalent. To install the light bulb:

1. Unscrew the Pen light tube halves. (Figure 7)
2. Remove the batteries.
3. Remove the metal tube from the plastic front tube.
4. Unscrew the old light bulb from the end of the tube and discard. (Figure 8)
5. Insert the new light bulb in the same place.
6. Replace the metal tube inside the pen light front tube.
7. Reassemble the housing to the original position.





Figure 3



Pen Light Figure 4




Figure 5



Figure 6



Figure 7




Figure 8

Spy Tool Kit
70021-4000-4L 2/99
Wild Planet Toys,Inc.



WARNING:

CHOKING HAZARD:Small Parts
Not for Children Under 3 Yrs.